

Hugiga_V8 VoLTE



1.功能表 → (確定)



2.設定 → 確定 (確定)




3.通話設定 → (確定)



4.Wi-Fi 通話 → (確定)



5.啟用 Wi-Fi 通話 → (確定)



6.撥號偏好 → (確定)



7.自行選擇 → (確定)