


【行動上網】Wi-Fi 通話




1.電話



2. ⋮



3.設定



4.通話帳戶



5.選擇 卡 1/卡 2



6.Wi-Fi 通話



7.Wi-Fi 通話 關



8.Wi-Fi 通話 開



9.上方列 